

## C7 Fire Extinguisher Mount

Fits C7 & Z06 Coupes with factory seats

The Brey-Krause R-2171 Fire Extinguisher Mount has been designed to bolt in without modification and provide a mounting point for an Amerex brand 2.5 lb. fire extinguisher w/mounting bracket.

### Step 1

Disconnect the lower shoulder harness strap from the seat. To do this, pop the plastic cover off and use a socket or torx to undo the retaining screw within.



### Step 2

Put Seat into front most position, and unbolt rear seat bolts using 15mm socket. Put Seats into rear most position and raise the front of the seat. Remove clips from covers on front seat bolts. Covers pull off in a 45 degree angle to the floor (see picture of clips below)



### Step 3

Unbolt front seat bolts using 15mm socket. Move the seat forward and tilt the back rest forward. Raise the front of the seat to its highest position. Disconnect battery ground cable. Unplug electrical connector at front of seat. To unplug the large plug, push in tongs at back of connector, and rotate purple tab downward, then pull apart. To unplug small plug (only on some models) insert small screwdriver into slot on bottom of connector and pull apart.

### Step 4

Remove roof panel. Remove seat from car, taking care not to hit the seat rails against any soft surfaces.

**Step 5**

Remove this nut on both sides of the seat.



**Step 6**

Install the mount plates so that the large hole goes over the front tube and the rear (smaller, offset) hole goes over the stud revealed by removing the nut. Reinstall nut.

**Step 7**

Use 4 included bolts and nylock nuts to attach the bar to the mounts. Final mounting should look as follows:



**Step 8**

Reinstall seat in car, making sure to reconnect seat wiring harness before reconnecting battery..

Performance driving events are by nature potentially hazardous to your health. Brey-Krause Mfg. Co. Inc. shall not be liable for injury, consequential, or other types of damages resulting from the use or misuse of our products. Proper installation of these parts is critical and should only be done by a professional shop.

